



- Notes/Parts
1. L1, L3 are
TOKO RMC-502182N0,
Digikey # TK1305-ND
These have 180 pf internal.
 2. L2 is
TOKO RUNS-T1028Z,
Digikey # TK1232-ND
 3. L4 is
TOKO 262LY-222K
Digikey # TK4396-ND
 4. Gain is about 0 db with W2 open,
6db with W2 jumpered. Remove
jumper W2 when using active
antenna preamp.
 5. Jumper W1 provides +8v power to
the active antenna preamp. Install
jumper only for use with preamp.

Revision History:
A: Added 'L4' to component designator list

Components:
R1-R5
C1-C6
L1-L4
Q1-Q2